RGB/CCT/Dimming 3 Channel LED RF Controller



Model No.: V3-X

3 Channels/10A per channel/Step-less dimming/Wireless remote control/Auto-transmitting/Synchronize



FC C CE RoHS [emc] LVD RED

Features

- Match with Skydance's 2.4G single color, dual color and RGB/RGBW remote control.
- One RF controller accept up to 10 remote control.
- When using with RGB light, built in 10 dynamic mode, include jump or gradual change style.
- Auto-transmitting function: Controller automaticly transmit signal to another controller with 30m control distance.
- Synchronize on multiple number of controllers.

Technical Parameters

Input and Output

| · · | |
|----------------|--------------------|
| Input voltage | 12-36VDC |
| Input current | 30.5A |
| Output voltage | 3 x (12-36)VDC |
| Output current | 3CH,10A/CH |
| Output power | 360-1080VV(12-36V) |
| Output type | Constant voltage |
| | |

Dimming data Input signal RF 2.4GHz

| Environment | |
|-------------------------|-------------------|
| Operation temperature | Ta: -30°C ~ +55°C |
| Case temperature (Max.) | Tc:+85°C |
| IP rating | IP20 |

5 years

Reverse Polarity


| Control distance | 30m |
|------------------|-------------|
| Dimming level | 4096 levels |
| Dimming range | 0 - 1 0 0% |
| Dimming curve | Logarithmic |
| PWM Frequency | 750Hz |
| | |
| Safety and EMC | |

| earery and Errie | |
|----------------------|--------------------|
| EMC standard (EMC) | EN301 489,EN 62479 |
| Safety standard(LVD) | EN60950 |
| Radio Equipment(RED) | EN300 328 |
| Certification | CE,EMC,LVD,RED |

Warranty and Protection

| Warranty | |
|------------|--|
| Protection | |


| User Ma | anual Ve | er 1.0.2 |
|---------|----------|----------|
| | | |



Mechanical Structures and Installations


Wiring Diagram

• V3-X for RGB




• V3-X for dual color





75.00 mm

• V3-X for single color



Match Remote Control (two match ways)

End user can choose the suitable match/delete ways. Two options are offered for selection:

Use the controller's Match key

Match:

Short press match key, immediately press on/off key (single zone remote) or zone key (multiple zone remote) of the remote.

Delete:

Press and hold match key for 5s to delete all match, The light blinks 5 times means all matched remotes were deleted.

Use Power Restart

Match:

Switch off the power, then switch on power again, immediately short press on/off key (single zone remote) or zone key (multiple zone remote) 3 times on the remote. The light blinks 3 times means match is successful.

Delete:

Switch off the power, then switch on power again, immediately short press on/off key (single zone remote) or zone key (multiple zone remote) 5 times on the remote. The light blinks 5 times means all matched remotes were deleted.

RGB Dynamic mode list

| No. | Name | No. | Name |
|-----|---------------------------|-----|-----------------------|
|] | RGB jump | 6 | RGB fade in and out |
| 2 | RGB smooth | 7 | Red fade in and out |
| 3 | 6 color jump | 8 | Green fade in and out |
| 4 | 6 color smooth | 9 | Blue fade in and out |
| 5 | Yellow cyan purple smooth | 10 | White fade in and out |


Dual color control

CH1=Warm white LED

CH2=Cool white LED

Each channel can supply up to 240W(@24V) and white balance can be controlled as such:

| Color temperature | Cool white | Neutral white | Warm white |
|--------------------|-----------------|-------------------|-----------------|
| Power distribution | CH1=0W,CH2=240W | CH1=120W,CH2=120W | CH1=240W,CH2=0W |



Malfunctions analysis & troubleshooting

| Malfunctions | Causes | Troubleshooting | |
|---|--|---|--|
| No light | No power. Wrong connection or insecure. | Check the power. Check the connection. | |
| Wrong color | 1. Wrong connection of R/G/B wires. | 1. Reconnect R/G/B wires. | |
| Uneven intensity between front and rear,with voltage drop | Output cable is too long. Wire diameter is too small. Overload beyond power supply capability. Overload beyond controller capability. | Reduce cable or loop supply. Change wider wire. Replace higher power supply. Add power repeater. | |
| No response from the remote | The battery has no power. Beyond controllable distance. The controller did not match the remote. | Replace battery. Reduce remote distance. Re-match the remote. | |